



ボタン操作



Button

RGBライトのオン/オフ

ボタンを短く1回押すと、
RGBライトのオン/オフを切り替えます。



67W
GaN LxVII
RGB Eco Fast Charger



BatteryEco

バッテリー保護機能

ボタンを約1.5秒間長押しすると、
BatteryEcoモードのオン/オフを切り替えられます。
オンにすると、各ポートの出力を最大5Wに制限し、
接続機器と充電器本体の発熱を抑えます。

www.physce.co.jp (Japan)
www.physce.com (Global)



RGBライティングパターン



Standby

待機中



約1秒

シアンからマゼンタへ、順番に変化します。



充電中 Charging

充電出力 < 20W



青、シアンの順に変化を繰り返します。

21W < 充電出力 < 36W



黄色、オレンジの順に変化を繰り返します。

充電出力 > 36W



赤、マゼンタの順に変化を繰り返します。





Button Controls



Button

RGB Light On/Off

Press the button once to turn the RGB lights on or off.



67W

GaN LXVII
RGB Eco Fast Charger



BatteryEco

BatteryEco Mode

Press and hold the button for about 1.5 seconds to turn BatteryEco mode on or off.
When enabled, each port is limited to 5W to reduce heat from both the device and charger.



www.physce.com (Global)
www.physce.co.jp (Japan)



RGB Lighting Effects Description



Standby



Standby



The light cycles from cyan to magenta at approximately 1-second intervals.

Power



Charging

Charging Output < 20W



The LED cycles through blue and cyan.

21W < Charging Output < 36W



The LED cycles through yellow and orange.

Charging Output > 36W



The LED cycles through red and magenta.

