




ボタン操作



Button

RGBライトのオン/オフ

ボタンを短く 1 回押すと、
RGBライトのオン/オフを切り替えます。

10⁺ physce Eco
PICO 3-nd Power Bank 10k


BatteryEco

BatteryEcoモード

ボタンを約 3 秒間長押しすると、
BatteryEcoモードのオン/オフを切り替えられます。

BatteryEcoモードが有効な場合は、緑色のライトのみ
点灯します。各ポートの出力を最大 5 W に制限し、接続機器
とモバイルバッテリー本体の発熱を抑えます。

※急速充電を行う場合は、BatteryEcoモードをオフにしてください。
※BatteryEcoモードは、モバイルバッテリー本体の充電にも適用されます。
※AC充電中に満充電になると、通常のライティング表示に切り替わります。




RGBライティング・パターン

Q Battery Status

バッテリー残量

- 76~100%
- 51~75%
- 26~50%
- 1~25%

バッテリー残量に応じて、下から順に
ライトが 1 つずつ点灯します。



バッテリーヘルス

- 緑：80%以上
- 黄：61~79%
- 赤：60%以下


充電していない状態でボタンを短く押すと、
4つのライトが順番に点灯した後、バッテリーヘルスが
色で表示されます。

Charging

急速充電時のライティング




急速充電中は、RGBライトがランダムな色で
点灯します。





Button Controls



 **Button**

RGB Light On/Off

Press the button once to turn the RGB lights on or off.

10⁺ physce Eco
RGB 3-in-1 Power Bank 10k


 **BatteryEco**

BatteryEco Mode

Press and hold the button for about 3 seconds to turn BatteryEco mode on or off.

When BatteryEco mode is enabled, only the green light remains on. Each port is limited to 5W to reduce heat generated by both the connected device and the power bank itself.

- For fast charging, turn BatteryEco mode off.
- BatteryEco mode also applies when charging the power bank itself.
- When the power bank reaches full charge in AC charging mode, the lighting returns to the normal pattern.




RGB Lighting Effects

Q Battery Status Battery Level



The lights indicate the remaining battery level, illuminating one by one from the bottom up.



Battery Health

-  Green: 80% or higher
-  Yellow: 61%~79%
-  Red: 60% or lower

When the power bank is neither charging nor discharging, press the button once. The four lights will illuminate in sequence, followed by a solid color indicating the battery health.

Charging

Lighting During Fast Charging



During fast charging, the RGB lights illuminate in random colors.

